

SMSIR6 – SMART IR REMOTE INSTALLATION INSTRUCTIONS

Description


The SMSIR6 remote is capable of operating over an unobstructed range of approximately 25 feet. Within this range, scenes can be selected, raised and lowered, and power may be turned On and Off using the handheld, wireless remote transmitter. In addition the SMSIR6 is capable of controlling up to 4 different SMST6 transmitters.

NOTE: This system is based on line-of-sight operations. Therefore, the receiver must be able to “See” the remote. Any obstruction between the remote and receiver may adversely affect the operations of the unit.


Programming

Programming the SMST6 SmartTransmitters.


1. While pointing SMSIR6 at the SMST6 transmitter PRESS and HOLD buttons RM 1 and RM 3 simultaneously for 3 seconds. The current room programmed will blink on the transmitter (Note: factory default is OFF).
2. Press room button that you want to program (RM 1, RM 2, RM 3, RM 4, OFF) button begins blinking.
3. Press ON to save and exit.



Front



SMST-6



Back

SMSIR6 – SMART IR REMOTE INSTALLATION INSTRUCTIONS


Replacing Battery

Installing and/or replacing the remote batteries:

The SMSIR6 remote operates on one 3-volt battery.

1. Turn the unit facedown.
2. Pull battery drawer out (see illustration)
3. Place new battery in drawer. Make sure battery polarity is inserted correctly or slide drawer cannot be reinserted into remote case.
4. Reinsert drawer into remote case.

NOTE: If unit has a battery paper insert hanging out of drawer, remove it in order to connect battery internally to remote.



Other

Remove protective film from keypad area of remote.

LIMITED WARRANTY

Seller warrants this product, if used in accordance with all applicable instruction, to be free from original defects in materials and workmanship for a period of three years from the date on serial number or purchase date if no S/N date is given. If the product should prove defective in material or workmanship within that period, Seller will repair or replace the product, at its sole discretion. Service under this warranty can only be obtained by delivering or shipping the product (with all shipping or delivery charges prepaid) to: Powerline Control Systems, 19201 Parthenia St., Suite J, Northridge, CA 91324. Seller will pay return shipping charges.

This warranty does not apply to normal wear or to damage resulting from accident, misuse, abuse or neglect. Seller makes no express warranties other than those expressly set forth herein. Except to the extent prohibited by applicable law, all implied warranties, including all warranties of merchantability or fitness, are limited in duration to the warranty period set forth above; and this warranty expressly excludes all incidental and consequential damages. (Some states do not allow limitations on how long an implied warranty lasts, and some states do not allow the exclusion or limitations of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from jurisdiction to jurisdiction.)